

Aqua Cycle Operating Instructions

Peddle Safe and Wear your Life Jacket at all times!



Seat Adjustment




Adjusting the seat height by renter is not recommended on this watercraft.

This watercraft only allows for minimal seat adjustment and is relatively difficult to do. If required, there is a thumb screw on each side that can be removed, moved to a new hole and replaced to make minor adjustments to height.

Steering handle left - Right Turn



Steering handle right – Left Turn



Steering of this paddle boat is from the back seat. At least one person must sit in the back seat to steer this paddle boat. To steer the paddle boat the steering handle should be moved to the left to turn right and moved to the right to turn left. To go straight, the handle should be pointed straight back. The paddle boat will only turn while moving.

Caution – Aluminum hull is slippery and can get hot in the sun!

For your safety and to avoid damage – Do not stand on seats or baskets, and do not hang from bimini top! We recommend that you take one or two canoe paddles with you as a backup in case a mechanical failure occurs.