

Kayak Carrier Instructions

1. Locate Carrier



If your party is unable to carry the Kayak a carrier is available to assist you. Please do not damage the Kayak by dragging it.

Carrier is located under the curtesy cell phone lockers (see 1.).

After loosening straps, lay carrier out as shown (see 2.) with room for kayak in front of wheels.

2. Loosen Straps and Position Carrier



3. Place Rear of Kayak on Carrier



Place the rear of Kayak on carrier as shown (see 3.) then adjust carrier into place by lifting stand (see 4.).

4. Raise Carrier Support to Kayak



5. Connect Back Strap




Connect strap closes to back of Kayak as shown through bungee cords to prevent carrier slippage (see 5.), tighten strap. Connect front strap and tighten (see 6.).

6. Connect Front Strap



7. Pick up front of Kayak by handle



Once you have verified that the Kayak Carrier is securely fastened to the Kayak, it can be easily pulled by the front handle.

Once you reach the EZ Dock, remove carrier.

Please return carrier to storage location for use by the next renter before launching your Kayak.

Paddle Safe, Wear a PFD!

8. Please return Carrier to storage

